

ATTENTION Pre-Loaded Card Customers:


Our Snowmobile + ORV GPS Map consists of **two separate maps**. We load both on the memory card so you can choose which to see in your GPS.

It's very **important to disable or "hide" one of these maps**, which is done on your GPS as listed below.

For example, if you are snowmobiling, you will want to hide/disable the ORV + Snowmobile; similarly if it's ORV season, you'll want to "Show" or "enable" the ORV + Snowmobile and "Hide" or "disable" the Snowmobile + ORV.



Most Handheld units (60C, eTrex, etc.):

1. Press the Page button until you are at the Map screen.
2. Press the Menu button.
3. Choose Setup Map.
4. Select the Map Info menu item (3rd from left at top, "i" symbol).
5. Press the Menu button.
6. Choose "Hide VVMapping..." from one of the the "VVMapping" items listed. Unfortunately these models can not display the entire map name, but they do list them alphabetically. The first one will be ORV + Snowmobile and the second will be Snowmobile + ORV.



Most Combo units (276C, etc.):


1. Press the Page button until you are at the Map screen.
2. Press the Menu button.
3. Choose Map Information.
4. Uncheck the box next to the listed maps that you want to disable.



Most Auto units (Nuvi, Colorado):

Please note, the Built-in maps must also be disabled to show our maps.

1. Press the Wrench icon.
2. Press the Map button.
3. Press the Map Info button.
4. Uncheck the box next to the listed maps that you want to disable.

1. From the Menu page, touch .
2. Touch the setting you want to change. Each setting contains a submenu or a list.

Changing the Map Settings

Touch  >  Map.

